

Procedure for Changing Sealed Air Foam Drums

1. When drums are low, use wedges provided to safely tip drums.
This will use the majority of liquid leaving one small cup full.
2. At this stage, collect full drum(s) from Warehouse.
3. If drum(s) are on a full pallet, move onto single pallet(s).
4. This must be done by 2 people.
Place the full pallet next to single pallet and slide/turn the drum moving onto a single pallet.
If changing both coloured drums, repeat with second drum moving onto another single pallet.
5. Using a pallet truck, take single pallet to the Pump Room and place in the hashed area.
6. Remove lid on full drum.
7. Ensuring you are working on the same colour drum, remove pipes from empty drum.
8. Place pipes onto new drum.
**NEVER MIX COLOURS, ALWAYS RED TO RED AND BLUE TO BLUE.
IF EVER MIXED REFER TO SEALED AIR MANUAL AS NOW CONTAMINATED.**
9. Using the pallet truck, take the empty drum to the storage area for disposal collection.
10. If changing the other coloured drum, using the pallet truck collect and take to the Pump room.
11. Repeat changing process on the other coloured drum.
**NEVER MIX COLOURS, ALWAYS RED TO RED AND BLUE TO BLUE.
IF EVER MIXED REFER TO SEALED AIR MANUAL AS NOW CONTAMINATED.**
12. Using the pallet truck take the empty drum to the storage area for disposal collection.
13. Using pallet truck place full drum(s) in designated place.